

APPLICATION INSTRUCTIONS



- 1 Allow your decal to sit for a bit at room temp. Then, clean the application area.

Rubbing alcohol can be used for most surfaces.

(Vinyl adheres best to hard, smooth surfaces.)

- 2 **BEFORE PEELING:** Using a credit card & flat hard surface, **FIRMLY** rub the clear front side of the entire decal (*each letter or section*) to make sure the decal is properly adhered to the clear transfer tape.

STOP



- 3 Starting in the corner, **SLOWLY** peel the paper backing (marked with grid lines) to reveal sticky side of decal. **If parts of the decal don't stay stuck to the clear transfer tape, repeat step #2.**



- 4 Carefully lay the sticky side of decal down on the application surface. Using a credit card, firmly squeegee over top of the clear transfer tape. **Apply firm pressure** while passing over the **entire** decal to ensure a strong bond.



Don't Forget Step 5

- 5 At a sharp angle, **SLOWLY** remove the clear transfer tape starting in the corner. Most small air bubbles will disappear after 48-72 hrs. Vinyl removable but NOT reusable. **You're finished!**

